


## Lc Multimode 12-core Terminal Box



## Lc Multimode 12-core Terminal Box



The 12 Port Fiber Distribution Box can connect up to 2 optical cables, providing space for distributors and 12 fuses. It is equipped with 12 SC adapters and can work in outdoor environments.



Feature: 12 ports optical fiber distribution box is used for the fusion splicing, splitting, wiring transmission and other functions of the optical transmission terminal; It can effectively terminate, protect and ...



The Haile 12-port 12-core terminal box P2A-12M-LC is a reliable and compact solution for managing fiber optic connections. It is designed for multi-mode Gigabit OM2 fiber, and includes LC connectors ...



The 12 cores plastic fiber optic distribution box provides a protected connection point for the feeder cable and drop cable in FTTH and FTTx networks. It integrates optical fibre splicing, splitting, distribution, ...



6-Core FTTH Fiber Distribution Termination Box with 6 SC APC Adapters, IP65 Waterproof, Wall-Mount Enclosure for Residential/Commercial Fiber Optic Splicing & Management (with 6 APC Adapter)




Welcome to buy our high quality products or wholesale our customized 12 lc duplex din rail fiber optic splice termination box in stock with our factory. Also, free sample is also available if necessary.



Equipped with a removable **Mounting Plate** inside the enclosure, enabling customized drilling and secure component mounting.

The Fibre Optic Terminal Box with DIN Rail is available for connection, distribution and termination of various types of fibre optic systems. It is particularly suitable for terminal distribution in mini-networks ...



□Application□The fiber optic distribution box is used for the integration of optical cables, as well as the fusion, winding, storage, and distribution of optical fibers.



YINGDA is always very fast to manufacture custom cables with high quality and reliability.



Â Color: 12 Core with LC Fiber Cable Coupler  
Features: Feature: 12 ports optical fiber distribution box is used for the fusion splicing, splitting, wiring transmission and other functions of the optical ...

## Contact Us

For more information, pricing, or custom network solutions, please contact us:

Website: <https://www.hashherbcafe.co.za>

Email: [hello@hashherbcafe.co.za](mailto:hello@hashherbcafe.co.za)

Phone: +27 63 814 7295

Address: 15 Galaxy Road, Linbro Business Park, Johannesburg, 2065, South Africa

This document is for informational purposes only. Specifications subject to change without notice.

